



Motorola EX115

Getting Started Guide

Congratulations

Motorola EX115

Your **Motorola** EX115 is a phone with premium features including music, photo, video, browsing and more—with an easy to use QWERTY keypad.

- **Music.** Play—instant music. Just open your media player and select a playlist.
- **Photos.** Use your phone's camera to take photos and send them to your friends.
- **Browsing.** Get more from the Web with a huge screen. Search, browse, everything you want to do, made easier.

We've crammed all the main features of your phone into this handy guide, and in a matter of minutes we'll show you just how easy your phone is to use. You may be surprised at what you discover.


Caution: Before assembling, charging or using your phone for the first time, please read "Safety, regulatory & legal" on page 34.

More

- **Accessories:** Find accessories for your phone at www.motorola.com/products.

Your phone

the important keys & connectors



Note: Your phone might look a little different.

Contents

Your phone	2
Let's go.	4
Keys	7
Home screen	9
Calls	11
Contacts	13
Messaging	15
Web	17
Bluetooth™ wireless	18
Manage your life	20
Tips & tricks	22
Personalise.	24
Text entry	26
Photos	27
Media player	29
Radio	31
Security	32
Troubleshooting.	33
Safety, regulatory & legal	34

Let's go

let's get you up and running

Assemble & charge

1 cover off



2 SIM cards in



3 battery in



4 microSD in



5 cover on




6 charge up



Note: EX115 dual SIM.

Caution: Please read “Battery use & safety” on page 34.


Turn it on & off

To turn your phone on or off, press and hold End .




Activate SIM cards

Your phone supports two SIM cards. When two SIM cards are installed, you can activate one or both SIM cards.


- 1 From the home screen, press **Menu** (left soft key) to open the main menu.
- 2 Select  **Settings** > **Dual SIM settings**.
- 3 Set mode to **Dual SIM open**, **Only SIM1 open**, **Only SIM2 open** or **Flight mode**.


Note: If only one SIM card is installed, it will be activated by default.

Make & answer calls

To make a call from the home screen, enter a number and press Call .

Note: If the **Dual SIM open** mode is activated, choose which SIM card to use.

To answer a call, press Call . To turn off the incoming call alert, press **Reject**.

To end a call, press End .

Cool content & more

Surf the Web for cool content and more. See “Web” on page 17. An optional microSD memory card can be installed in your phone—you can load it up with photos, videos and music from your computer.

Keys


a few essentials


Key tips


Here are some tips on how to navigate around your phone.

Menu navigation

- 1 From the home screen, press **Menu** (left soft key) to open the main menu.


Tip: You can also press  to open the main menu



- 2 Press  up, down, left or right to scroll and highlight a menu option.

- 3 Press  to select the highlighted option.



Shortcut keys

From the home screen press the navigation key  up, down, left or right to quickly open **Media player**, **Alarm**, **User profiles** or **Tone settings**.

To change your shortcut keys press  >  **Settings** > **Phone settings** > **Dedicated key**.


Adjust volume


Press the volume keys on the side of your phone to change the ring volume (in the home screen), or the earpiece volume (during a call).

Home screen

quick access to the things you need most

Quick start: home screen




The *home screen* gives you all your latest information in one place. It's what you see when you turn on the phone or press End  from a menu. It's basically like this:



Note: Your home screen might look a little different.













Main menu

All the apps on your phone are shown in your *main menu*.

To open the main menu, from the home screen, press **Menu** (left soft key). Press  up, down, left or right to highlight a menu option, then press  to select the highlighted option. You can press End  to return to the home screen at any time.

Phone status & notifications



The status bar at the top of the screen contains icons that tell you about messages and phone status.

status indicators			
	Signal strength		General profile
	Active voice call		Meeting profile
	Phone lock		Outdoor profile
	Alarm lock		Headset
	Roaming service		Bluetooth
	New messages		Battery

Calls

it's good to talk

In-call options



During a call, press **Options** to hold, end or make a new call, and more. Press **Mute** to mute your call. Press  to turn the loudspeaker on and press  again to turn the loudspeaker off.

Note: If two SIM cards are installed, choose which you want to use.

Redial

- 1 Press  >  **Call center** > **Call history**

Note: If two SIM cards are installed, choose which you want to use.


- 2 Highlight the history you want to use (**SIM1 call history** or **SIM2 call history**) and press 
- 3 Highlight the contact you want to call and press Call .

Save a contact

- 1 Enter a number in the home screen.
- 2 Press **Options** > **Save to Phonebook** > **Add new contact** or **Replace existing**.
- 3 Enter contact details and press **Done**, then **Yes**.

Emergency calls

Note: Your service provider programmes one or more emergency phone numbers (such as 999 or 110) that you can call under any circumstances, even when your phone is locked. Emergency numbers vary by country. Your pre-programmed emergency number(s) may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental or interference issues.


- 1 Enter the emergency number in the home screen.
- 2 Press Call  to call the emergency number.


Contacts

contacts like you've never had before

Quick start: Contacts

Find it:  >  **Phonebook**




Tip: To see more contacts, press  up or down.


Create contacts

Find it:  >  **Phonebook** > **Add new contact**

Enter the contact name and details, then press **Done** > **Yes**.

Call contacts

Highlight a contact, then press Call .

Tip: Press the volume keys to scroll to a contact, then press Call .

Messaging

sometimes it's best to text or email...

Create & send messages

Find it:  >  **Messaging > Write message**


Use the keypad to enter your message.

Press **Options** to insert a picture, sound or video.


When you've finished composing the message, press **Options > Send to** to enter phone numbers or select message recipients from your phonebook.

To send the message, press **Options > Send**.

Receive a message

When you receive a message, your phone plays an alert and shows the new message indicator  at the top of the screen.

To read the new message, press **View**.

To read messages stored in your inbox, press  **Messaging > Inbox**.

Email

Set up an account

Find it:  >  **Messaging > Email**

> **Email accounts**, press **Options > New account**
> **Yes**

The email setup wizard will guide you through setting up your email account.

Create a new email

Find it:  >  **Messaging > Email > Write Email**

Enter the recipient email address and message, then press **Done > Send**.


Web

you don't need a PC, surf the web with your phone

Note: To use the browser, you must have data services activated for your account (additional fees may apply for this service).

Use your phone's browser to surf your favourite Web sites, upload videos to a video blog and download files and applications to your phone. Log onto your Internet-based email account to check your email.

Find it:  >  **Services > Internet service**

- To go to your home page, press **Homepage**.
- To go to a Web page, press **Input address**.
- To bookmark a Web page, press **Options > Add to Bookmarks**.
- To go to a link on a Web page, highlight it and press .


Note: If you can't connect, contact your service provider.

Bluetooth™ wireless

lose the wires and go wireless

Turn Bluetooth power on or off



Find it:  >  **Settings > Connectivity > Bluetooth > Power**

When Bluetooth power is on, the Bluetooth indicator  appears in the home screen.


Note: To extend battery life, turn off Bluetooth power when not in use.

Connect new devices

To connect with a new device, you need to pair with it. You only need to do this once for each device—to connect again, see “Reconnect devices” on page 19.

- 1 Make sure the device you are pairing with is in discoverable mode (see device instructions).
- 2 Press  >  **Settings > Connectivity > Bluetooth > Search audio device.**

Note: If Bluetooth power is not turned on, your phone will ask if you want to **Power on Bluetooth first?** Press **Yes**.

- 3 Your phone lists the devices it finds within range. Highlight a device and press  to connect.

- 4 If necessary, enter the device passkey (like **0000**) to connect to the device.

Tip: For specific information about a device, check the instructions that came with it. For more Bluetooth support, go to www.motorola.com/Bluetoothsupport.

For maximum Bluetooth security, always connect Bluetooth devices in a safe, private environment.

Note: Using a mobile device or accessory while driving may cause distraction and may be illegal. Always obey the local laws and drive safely.

Reconnect devices

To **automatically reconnect** your phone with a paired device, simply turn on the device.

To **manually reconnect** your phone with a paired device, select the device name in the **My device** list.

Disconnect devices

To **automatically disconnect** your phone from a paired device, simply turn off the device.

To **manually disconnect** your phone from a paired device, select the device name in the **My device** list.

Manage your life

stay on top of things

Calendar

Find it:  >  **Organiser > Calendar**

To view your calendar in different ways press **Options > Jump to date** or **Go to weekly view**.

Add calendar events

From any calendar view, press **Options > Add event > Reminder, Meeting or Course**. Enter event details and press **Options > Done > Yes**.

Edit calendar events

To edit an event, press **Options > View > Options > Edit**. Edit event details and when you've finished, press **Options > Done > Yes**.

Tasks

Find it:  >  **Organiser > Tasks**

To add a task, press **Add > Date, Call or Anniversary**.

Alarm

Find it:  >  **Organiser > Alarm**

To turn on an alarm, highlight it and press , scroll to **On** and press **Done > Yes**.

When an alarm sounds, press **Stop** to turn it off or **Snooze** to delay.

To set a snooze period, highlight the alarm, then press **Edit** > **Snooze (min)**.

To set FM radio as your alarm, highlight the alarm, then press **Edit** > **Alarm tone** > **FM radio**.

World clock

Find it:  >  **Organiser** > **World clock**

See the current time in cities around the world.

To set the clock to allow for daylight saving time, press **Options** > **Daylight saving time for foreign city** > **On** or **Off**.


Calculator & currency converter

Find it:  >  **Extra**

Just scroll and select to open the **Calculator** or **Currency converter**.





File manager

Find it:  >  **File manager**

Highlight **Phone** or **Memory card** and press  to view your folders. Press **Options** to **Open**, create **New folder**, **Rename**, **Delete** and more.

Tips & tricks



a few handy hints

To...	
Return to home screen	Press End  .
See recently dialled numbers	Press  > Call center > Call history .
Create a new contact in your phonebook	Enter a phone number, press Options > Save to Phonebook .
Adjust sound volume	Press the up/down volume keys.
Set main menu style	View the main menu as a Matrix or List : Press  >  Settings > Phone settings > Display > Main menu style .

Battery tips

Want to extend your battery life? Try these:

- Turn off Bluetooth™ power: press  >  **Settings** > **Connectivity** > **Bluetooth** > **Power**.

- Reduce the time your phone display stays on:
press  >  **Settings** > **Phone settings**
> **Misc. settings** > **LCD backlight**, and set
Time (sec) to a lower setting.

Personalise

add your personal touch

Profiles

Your phone has different profiles. You can customise ringtones, alerts and volumes for each profile.

Find it:  >  **User profiles**

You can select these profiles:



- **General:** Standard profile default setting.
- **Outdoor:** Ringtone and key tone volume set to maximum.
- **Indoor:** Vibrate is off, ringtone is on.
- **Vibration:** Vibrate is on, ringtone is off.
- **Headset:** Adjust settings for when a wired headset is plugged into your phone.
- **Bluetooth:** Adjust settings for when a Bluetooth headset is connected to your phone.

To **change** a profile's settings, press **Options** > **Customise**. You can adjust these settings:

- **Tone settings:** Set the ringtones of incoming calls and messages (for each SIM card), key tones and other events.
- **Volume:** Set the volume of ringtones and key tones.

- **Alert type:** Set to **Ring only**, **Vib. only**, **Vib. and ring**, **Vib. then ring** and **Silent**.
- **Ring type:** Set to **Single**, **Repeat**, **Ascending**.
- **Extra tone:** Play an extra tone for **Warning**, **Error**, **Camp on** or **Connect**.
- **Answer mode:** Set to **Any key** to answer calls by pressing any key.

Display settings

To set display settings such as wallpaper and screen saver, press  >  **Settings** > **Phone settings** > **Display**.

Date & time

Set date, time, time zone and formats:

Find it:  >  **Settings** > **Phone settings** > **Time and date**

Language

Set menu language:

Find it:  >  **Settings** > **Phone settings** > **Language**


Text entry

think keyboard, now think smaller

Use the keypad to enter text and create messages or notes.

To **change** the keypad text entry mode, press **Options** > **Input method**. You can select these input methods:

- **abc**: Enter lowercase letters in the text field.
- **Numeric**: Enter numbers in the text field.
- **Insert symbol**: Select a symbol to insert.


To **delete** letters to the left of the cursor, press Back .

Photos

see it, capture it, share it!


Take & share photos

Take that family photo and send it to everyone.

Find it: Press Camera 

Select to increase/
decrease exposure.

Select to zoom in/out.





Select to switch to
photo album or video.

Select to take photo.

Select to return to
homescreen.

Note: Image size is 3MP, unless you change it.

To take the photo, press Camera  or . Your photo is shown in the viewfinder.

Press the left soft key, then:

- To **send** the photo in a message, email or via bluetooth, select **Forward**.
- To **edit** the photo, select **Photo editor**.

- To **delete** the photo and return to the viewfinder, select **Delete**.

To **see photos** you've taken, go to the camera viewfinder screen and press the left soft key then **Switch to > Photo album**.

To **record a video**, go to the camera viewfinder screen and press the left soft key then **Switch to > Video recorder**.


Media player

when music is what you need...




Media player

Just open your media player and select a playlist.


Find it:  >  **Multimedia > Media player**
> **My playlists**




Media player controls



controls	
play/pause	Press  up.
previous/next	Press  left/right.
fast forward/rewind	Press and hold  left/right.
volume	Press the side volume keys.

Hide and turn off

Press End  to use another app. Your media continues to play. If you use **Fun & Games** or **FM radio** the media player is turned off.

To turn off your media, press  down.

Playlists

To create a new playlist, press  >  **Multimedia**
> **Media player** > **My playlists** > **Options**
> **Create playlist**.

To add a song or video to a playlist, open the playlist, then press **Options** > **Add**.

To delete or rename playlists, press **Options**.

Radio

news and music on the go


Listen to news and music anywhere, for free.

Find it:  >  **Multimedia > FM radio**

Note: The FM radio only works when a headset is plugged in.

To tune stations, press **Options > Auto search**.

To change volume, press the side volume keys.

To turn off the radio, press  down.

Use radio presets

To **go to** a preset station, press **Options > Channel list**, then the channel number.

Security

help keep your phone safe

Codes & passwords

Your phone password is originally set to **1234**. If your service provider didn't change the phone password, you should change it:



Find it:  >  **Settings > Security settings > SIM1/SIM2 security settings > Change password**

You can also change your SIM card **PIN** and **PIN2** codes.

If you forget your phone password: At the **Input password** prompt, try entering **1234** or the last four digits of your phone number. If that doesn't work, contact your service provider.

If you forget other codes: If you forget your SIM PIN or PIN2, contact your service provider.

Lock keypad

Find it:  >  **Settings > Security settings > Auto keypad lock > 5 sec, 30 sec, 1 min or 5 min**

You can lock your phone's keypad and keys to prevent unwanted phone operations.

Your phone automatically locks the keypad and keys when no activity is detected for the specified interval.

To **unlock** the keypad and keys, press **Unlock** then .

Troubleshooting

we're here to help



Crash recovery

In the unlikely event that your phone stops responding to key presses, try a quick reset. Remove the back cover and battery (“Assemble & charge” on page 4), then replace and turn on your phone as usual.

Reset

Reset default factory settings on your phone.

Caution: This option erases all information you have entered (including contacts and calendar entries) and content you have downloaded (including pictures, videos and music files) stored in your phone’s memory. After you erase the information, you can’t recover it. This option does not delete SIM card or memory card information.

Find it:  >  **Settings > Restore factory settings**

Safety, regulatory & legal

Battery use & safety

Important: Handle and store batteries properly to avoid injury or damage. Most battery issues arise from improper handling of batteries, and particularly from the continued use of damaged batteries.

DON'Ts

- **Don't disassemble, crush, puncture, shred or otherwise attempt to change the form of your battery.**
- **Don't let the mobile device or battery come in contact with water.*** Water can get into the mobile device's circuits, leading to corrosion. If the mobile device and/or battery get wet, have them checked by your service provider or contact Motorola, even if they appear to be working properly.*
- **Don't allow the battery to touch metal objects.** If metal objects, such as jewellery, stay in prolonged contact with the battery contact points, the battery could become very hot.
- **Don't place your mobile device or battery near a heat source.*** Excessive heat can damage the mobile device or the battery. High temperatures can cause the battery to swell, leak or malfunction. Therefore:
- **Don't dry a wet or damp battery with an appliance or heat source,** such as a hairdryer or microwave oven.

DOs

- **Do avoid leaving your mobile device in your car in high temperatures.***
- **Do avoid dropping the battery or mobile device.*** Dropping these items, especially on a hard surface, can potentially cause damage.*

- **Do contact your service provider or Motorola if your mobile device or battery has been damaged from dropping or high temperatures.**

* **Note:** Always make sure that the battery compartment is closed and secure to avoid direct exposure of the battery to any of these conditions.

Important: Use Motorola Original products for quality assurance and safeguards.

To assist consumers in differentiating authentic Motorola batteries from non-original or counterfeit batteries (that may not have adequate safety protection), Motorola provides holograms on its batteries. Consumers should confirm that any battery that they purchase has a "Motorola Original" hologram.

Motorola recommends that you always use Motorola-branded batteries and chargers. Motorola mobile devices are designed to work with Motorola batteries. If you see a message on your display such as **Invalid Battery** or **Unable to Charge**, take the following steps:

- Remove the battery and inspect it to confirm that it has a "Motorola Original" hologram;
- If there is no hologram, the battery is not a Motorola battery;
- If there is a hologram, replace the battery and try charging it again;
- If the message remains, contact a Motorola authorised service centre.

Important: Motorola's warranty does not cover damage to the mobile device caused by non-Motorola batteries and/or chargers.

Warning: Use of a non-Motorola battery or charger may present a risk of fire, explosion, leakage or other hazard.

Proper and safe battery disposal and recycling: Proper battery disposal is not only important for safety, it benefits the environment. Consumers may recycle their used batteries in many retail or service provider locations. Additional information on proper disposal and recycling may be found on the web:

- www.motorola.com/recycling
- www.rbrc.org/call2recycle/ (in English only)

Disposal: Promptly dispose of used batteries in accordance with local regulations. Contact your local recycling centre or national recycling organisations for more information on how to dispose of batteries.



Warning: Never dispose of batteries in a fire because they may explode.

Battery Charging

Notes for charging your product's battery:

- When charging your battery, keep it near room temperature. Never expose batteries to temperatures below 0°C (32°F) or above 45°C (113°F) when charging.
- New batteries are not fully charged.
- New batteries or batteries stored for a long time may take more time to charge.
- Motorola batteries and charging systems have circuitry that protects the battery against damage from overcharging.

Driving Precautions

Responsible and safe driving is your primary responsibility when behind the wheel of a vehicle. Using a mobile device or accessory for a call or other application while driving may cause distraction. Using a mobile device or accessory may be prohibited or restricted in certain areas, always obey the laws and regulations on the use of these products.

While driving, NEVER:

- Type or read texts.
- Enter or review written data.
- Surf the web.
- Input navigation information.
- Perform any other functions that divert your attention from driving.

While driving, ALWAYS:

- Keep your eyes on the road.
- Use a hands-free device if available or required by law in your area.
- Enter destination information into a navigation device **before** driving.
- Use voice-activated features (such as voice dial) and speaking features (such as audible directions), if available.
- Obey all local laws and regulations for the use of mobile devices and accessories in the vehicle.
- End your call or other task if you cannot concentrate on driving.

Remember to follow the “Smart Practices While Driving” in this guide and at www.motorola.com/callsmart.

Seizures/Blackouts

Some people may be susceptible to epileptic seizures or blackouts when exposed to flashing lights, such as when playing videos or games. These may occur even if a person has never had a previous seizure or blackout.

If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult with your doctor before playing videos or games or enabling a flashing lights feature (if available) on your mobile device.

Discontinue use and consult a doctor if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements or disorientation. It is always a good idea to hold the screen away from your eyes, leave the lights on in the room, take a 15-minute break every hour and stop use if you are tired.

Caution About High Volume Usage

Warning: Exposure to loud noise from any source for extended periods of time may affect your hearing. The



louder the volume sound level, the less time is required before your hearing could be affected. To protect your hearing:

- Limit the amount of time that you use headsets or headphones at high volume.
- Avoid turning up the volume to block out noisy surroundings.
- Turn the volume down if you can't hear people speaking near you.

If you experience hearing discomfort, including the sensation of pressure or fullness in your ears, ringing in your ears or muffled speech, you should stop listening to the device through your headset or headphones and have your hearing checked.

For more information about hearing, see our website at direct.motorola.com/hellomoto/nss/AcousticSafety.asp.

Repetitive Motion

When you repetitively perform actions such as pressing keys or entering finger-written characters, you may experience occasional discomfort in your hands, arms, shoulders, neck or other parts of your body. If you continue to have discomfort during or after such use, stop use and see a doctor.

[Nov0109]

Small Children

Keep your mobile device and its accessories away from small children. These products are not toys and may be hazardous to small children. For example:

- A choking hazard may exist for small, detachable parts.
- Improper use could result in loud sounds, possibly causing hearing injury.
- Improperly handled batteries could overheat and cause a burn.

Glass Parts

Some parts of your mobile device may be made of glass. This glass could break if the product is dropped on a hard surface or receives a substantial impact. If glass breaks, do not touch or attempt to remove it. Stop using your mobile device until the glass has been replaced by a qualified service centre.

Operational Warnings

Obeys all posted signs when using mobile devices in public areas.



Potentially Explosive Atmospheres





Areas with potentially explosive atmospheres are often, but not always, posted and can include fuelling areas, such as below decks on boats, fuel or chemical transfer or storage facilities or areas where the air contains chemicals or particles, such as grain dust or metal powders.

When you are in such an area, turn off your mobile device, and do not remove, install or charge batteries. In such areas, sparks can occur and cause an explosion or fire.

Symbol Key

Your battery, charger or mobile device may contain symbols, defined as follows:

Symbol	Definition
	Important safety information follows.
	Do not dispose of your battery or mobile device in a fire.

Symbol	Definition
	Your battery or mobile device may require recycling in accordance with local laws. Contact your local regulatory authorities for more information.
	Do not dispose of your battery or mobile device with your household waste. See "Recycling" for more information.
	For indoor use only.
	Listening at full volume to music or voice data through a headset may damage your hearing.

Radio Frequency (RF) Energy

Exposure to RF Energy

Your mobile device contains a transmitter and receiver. When it is ON, it receives and transmits RF energy. When you communicate with your mobile device, the system handling your call controls the power level at which your mobile device transmits.

Your mobile device is designed to comply with local regulatory requirements in your country concerning exposure of human beings to RF energy.

RF Energy Operational Precautions

For optimal mobile device performance, and to ensure that human exposure to RF energy does not exceed the guidelines set forth in the relevant standards, always follow these instructions and precautions:

- When placing or receiving a phone call, hold your mobile device just like you would a landline phone.

- If you wear the mobile device on your body, always place the mobile device in a Motorola-supplied or approved clip, holder, holster, case or body harness. If you do not use a body-worn accessory supplied or approved by Motorola, keep the mobile device and its antenna at least 2.5 centimeters (1 inch) from your body when transmitting.
- Using accessories not supplied or approved by Motorola may cause your mobile device to exceed RF energy exposure guidelines. For a list of Motorola-supplied or approved accessories, visit our website at: www.motorola.com.

RF Energy Interference/Compatibility

Nearly every electronic device is subject to RF energy interference from external sources if inadequately shielded, designed or otherwise configured for RF energy compatibility. In some circumstances, your mobile device may cause interference with other devices.

Follow Instructions to Avoid Interference Problems

Turn off your mobile device in any location where posted notices instruct you to do so.

In an aircraft, turn off your mobile device whenever instructed to do so by airline staff. If your mobile device offers a flight mode or similar feature, consult airline staff about using it in flight.

Implantable Medical Devices

If you have an implantable medical device, such as a pacemaker or defibrillator, consult your doctor before using this mobile device.

Persons with implantable medical devices should observe the following precautions:

- ALWAYS keep the mobile device more than 20 centimeters (8 inches) from the implantable medical device when the mobile device is turned ON.
- DO NOT carry the mobile device in a breast pocket.

- Use the ear opposite the implantable medical device to minimise the potential for interference.
- Turn OFF the mobile device immediately if you have any reason to suspect that interference is taking place.

Read and follow the directions from the manufacturer of your implantable medical device. If you have any questions about using your mobile device with your implantable medical device, consult your healthcare provider.

Specific Absorption Rate (ICNIRP)

Your model wireless phone meets international guidelines for exposure to radio waves.

Your mobile device is a radio transmitter and receiver. It is designed to not exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organisation ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health, and to account for any variations in measurements.

The guidelines use a unit of measurement known as the Specific Absorption Rate (SAR). The ICNIRP SAR limit for mobile devices used by the general public is 2 watts per kilogram (W/kg), and the highest SAR value for this mobile device when tested at the ear is 0.684 W/kg. As mobile devices offer a range of functions, they can be used in other positions, such as on the body as described in this guide. In this case, the highest tested SAR value is 0.893 W/kg. The tests are carried out in accordance with international guidelines for testing. The SAR information includes the Motorola testing protocol, assessment procedure and measurement uncertainty range for this product.

As SAR is measured utilising the mobile device's highest transmitting power, the actual SAR of this mobile device while operating is typically below that indicated above. This is due to

automatic changes to the power level of the mobile device to ensure that it only uses the minimum level required to reach the network.

While there may be differences between the SAR levels of various mobile devices and at various positions, they meet the governmental requirements for safe exposure. Please note that improvements to this product model could cause differences in the SAR value for later products; in all cases, products are designed to be within the guidelines.

The World Health Organisation has stated that present scientific information does not indicate the need for any special precautions for the use of mobile devices. They note that if you want to reduce your exposure, then you can do so by limiting the length of calls or using a hands-free device to keep the mobile device away from the head and body.

Additional Information can be found on the websites of the World Health Organisation (<http://www.who.int/emf>) or Motorola Mobility, Inc. (<http://www.motorola.com/rfhealth>).

Information from the World Health Organisation

"Present scientific information does not indicate the need for any special precautions for the use of mobile phones. If you are concerned, you may want to limit your own or your children's RF exposure by limiting the length of calls or by using hands-free devices to keep mobile phones away from your head and body."

Source: WHO Fact Sheet 193


Further information: <http://www.who.int/peh-emf>

European Union Directives Conformance Statement

CE 0168

Hereby, Motorola declares that this product is in compliance with:

- The essential requirements and other relevant provisions of Directive 1999/5/EC
- All other relevant EU Directives



The above is an example of a typical Product Approval Number. You can view your product's Declaration of Conformity (DoC) to Directive 1999/5/EC (to R&TTE Directive) at www.motorola.com/rtte. To find your DoC, enter the Product Approval Number from your product's label in the "Search" bar on the website.

FCC Notice to Users

The following statement applies to all products that have received FCC approval. Applicable products bear the FCC logo and/or an FCC ID in the format FCC ID:xxxxxx on the product label.

Motorola has not approved any changes or modifications made to this device by the user. Any changes or modifications could void the user's authority to operate the equipment. See 47 CFR Sec. 15.21.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. See 47 CFR Sec. 15.19(3).

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by taking one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a different circuit from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Smart Practices While Driving

Check the laws and regulations on the use of mobile devices and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas – for example, hands-free use only may be required.

Go to www.motorola.com/callsmart for more information.

Your mobile device lets you communicate by voice and data – almost anywhere, anytime, wherever wireless service is available

and safe conditions allow. When driving a car, driving is your first responsibility. If you choose to use your mobile device while driving, remember the following tips:

- **Get to know your Motorola mobile device and its features such as speed dial, redial and voice dial.** If available, these features help you to place your call without taking your attention off the road.
- **When available, use a hands-free device.** If possible, add an additional layer of convenience to your mobile device with one of the many Motorola Original hands-free accessories available today.
- **Position your mobile device within easy reach.** Make sure that you can access your mobile device without removing your eyes from the road. If you receive an incoming call at an inconvenient time, if possible, let your voice mail answer it for you.
- **Let the person that you are speaking with know that you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions.** Rain, sleet, snow, ice and even heavy traffic can be hazardous.
- **Do not take notes or look up phone numbers while driving.** Jotting down a "to do" list or going through your address book takes attention away from your primary responsibility – driving safely.
- **Dial sensibly and assess the traffic; if possible, place calls when your car is not moving or before pulling into traffic.** If you must make a call while moving, dial only a few numbers, check the road and your mirrors, then continue.
- **Do not engage in stressful or emotional conversations that may be distracting.** Make people that you are speaking with aware that you are driving and suspend conversations that can divert your attention away from the road.
- **Use your mobile device to call for help.** Dial 999 or another local emergency number in the case of fire, traffic accident or

medical emergencies (wherever wireless phone service is available).

- **Use your mobile device to help others in emergencies.** If you see a car accident, crime in progress or other serious emergency where lives are in danger, call 999 or another local emergency number (wherever wireless phone service is available), as you would want others to do for you.
- **Call roadside assistance or a special non-emergency wireless assistance number when necessary.** If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured or a vehicle that you know to be stolen, call roadside assistance or another special non-emergency wireless number (wherever wireless phone service is available).

Privacy & Data Security

Motorola understands that privacy and data security are important to everyone. Because some features of your mobile device may affect your privacy or data security, please follow these recommendations to enhance protection of your information:

- **Monitor access** - Keep your mobile device with you and do not leave it where others may have unmonitored access. Lock your device's keypad if this feature is available.
- **Keep software up to date** - If Motorola or a software/application vendor releases a patch or software fix for your mobile device that updates the device's security, install it as soon as possible.
- **Secure Personal Information** - Your mobile device can store personal information in various locations including your SIM card, memory card and phone memory. Make sure that you remove or clear all personal information before you recycle, return or give away your device. You can also back up your personal data for transfer to a new device.

Note: For information on how to back up or wipe data from your mobile device, go to www.motorola.com/support

- **Online accounts** - Some mobile devices provide a Motorola online account (such as MOTOBLUR). Go to your account for information on how to manage the account, and how to use security features such as remote wipe and device location (where available).
- **Applications** - Install third-party applications from trusted sources only. Applications can have access to private information such as call data, location details and network resources.
- **Location-based information** - Location-based information includes information that can be used to determine the approximate location of a mobile device. Mobile phones that are connected to a wireless network transmit location-based information. Devices enabled with GPS or AGPS technology also transmit location-based information. In addition, if you use applications that require location-based information (e.g. driving directions), such applications transmit location-based information. This location-based information may be shared with third parties, including your wireless service provider, applications providers, Motorola and other third parties providing services.
- **Other information that your device may transmit** - Your device may also transmit testing and other diagnostic (including location-based) information, and other non-personal information to Motorola or other third-party servers. This information is used to help improve products and services offered by Motorola.

If you have further questions on how the use of your mobile device may effect your privacy or data security, please contact Motorola at privacy@motorola.com, or contact your service provider.

Use & Care

To care for your Motorola mobile device, please observe the following:



liquids

Don't expose your mobile device to water, rain, extreme humidity, sweat or other liquids. If it does get wet, don't try to accelerate drying with the use of an oven or dryer, as this may damage the mobile device.



Extreme heat or cold

Avoid temperatures below 0°C/32°F or above 45°C/113°F.



Microwaves

Don't try to dry your mobile device in a microwave oven.



Dust and dirt

Don't expose your mobile device to dust, dirt, sand, food or other inappropriate materials.



Cleaning solutions

To clean your mobile device, use a dry soft cloth only. Don't use alcohol or other cleaning solutions.



Shock and vibration

Don't drop your mobile device.



Protection

To help protect your mobile device, always make sure that the battery compartment and any connector covers are closed and secure.

Recycling

Mobile Devices & Accessories

Please do not dispose of mobile devices or electrical accessories (such as chargers, headsets or batteries) with your household waste, or in a fire. These items should be disposed of in accordance with the national collection and recycling schemes operated by your local or regional authority. Alternatively, you may return unwanted mobile devices and electrical accessories to any Motorola Approved Service Centre in your region. Details of Motorola-approved national recycling schemes, and further information on Motorola recycling activities can be found at: www.motorola.com/recycling

Packaging & Product Guides

Product packaging and product guides should only be disposed of in accordance with national collection and recycling requirements. Please contact your regional authorities for more details.

Software Copyright Notice

Motorola products may include copyrighted Motorola and third-party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola and third-party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in Motorola products may not be modified, reverse-engineered, distributed or reproduced in any manner to the extent allowed by law. Furthermore, the purchase of Motorola products shall not be deemed to grant either directly or by implication, estoppel or otherwise, any licence under the copyrights, patents or patent applications of Motorola or any third-party software provider, except for the normal, non-exclusive, royalty-free licence to use that arises by operation of law in the sale of a product.

Content Copyright

The unauthorised copying of copyrighted materials is contrary to the provisions of the Copyright Laws of the United States and other countries. This device is intended solely for copying non-copyrighted materials, materials in which you own the copyright, or materials which you are authorised or legally permitted to copy. If you are uncertain about your right to copy any material, please contact your legal advisor.

Copyright & Trademarks

Motorola. Inc.

852-25063888 (HK)

www.motorola.com.hk (HK)

Certain features, services and applications are network dependent and may not be available in all areas; additional terms, conditions and/or charges may apply. Contact your service provider for details.

All features, functionality and other product specifications, as well as the information contained in this guide, are based upon the latest available information and believed to be accurate at the time of printing. Motorola reserves the right to change or modify any information or specifications without notice or obligation.

MOTOROLA, the Stylised M Logo, MOTOBUR and the MOTOBUR logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. The Bluetooth trademarks are owned by their proprietor and used by Motorola Mobility, Inc. under licence.  is a Certification Mark of the Wireless Fidelity Alliance, Inc. Java and all other Java-based marks are trademarks or registered trademarks of Sun Microsystems, Inc. in the US and other countries. Google, YouTube, Picasa, Gmail and the Google logo are trademarks of Google, Inc. Facebook is a registered trademark of Facebook, Inc. Microsoft, Windows, Windows Me and Windows Vista are registered trademarks of Microsoft Corporation in the United States and other countries. Apple, Macintosh, Quicktime and Quicktime logo are registered trademarks of Apple Computer, Inc. iTunes is a trademark of Apple Computer, Inc., registered in the US and other countries. All rights reserved. America Online, AOL, the America Online & Design logo, the AOL & Design logo and the Triangle Logo are registered trademarks of America Online, Inc. in the United States and/or other countries. Instant Messenger and Buddy List are trademarks

of America Online, Inc. All other product or service names are the property of their respective owners.

© 2010 Motorola Mobility, Inc. All rights reserved.

Caution: Changes or modifications made in the radio phone, not expressly approved by Motorola, will void the user's authority to operate the equipment.

Product ID: Motorola EX115

Manual Number: 68014587001

accessories



more information



GO TO

www.motorola.com.hk



68014587001